



MIDI OUTPUT

BY DEFAULT, THE MM-1 SENDS MESSAGES OUT ON
ON MIDI CHANNEL 5.

LED FEEDBACK

TO DRIVE THE LED FOR A SPECIFIC CONTROL, SEND THE OUTPUT MESSAGE
FOR THAT CONTROL BACK TO THE MM-1.

LAST BYTE VALUES BELOW CONTROL LED STATE.

BUTTONS - 00 - "OFF" / 01 - ON SOLID / 02 - ON BLINKING

PEAK METERS ~ RANGE IS 48 THRU 63

CMD MM-1 MIDI MAP